

## Produktinformation



## Information

Tillverkare	HP
Artnr	1JR31AA#AC3

**HP Premium - Mus - höger- och vänsterhänta  
- laser - 3 knappar - trådlös - 2.4 GHz - trådlös  
USB-mottagare - svart - för HP 240 G8, 24X G7,  
25X G8; EliteDesk 805 G6; Pro c645; ProBook  
440 G8, 635; ProDesk 405 G6**

## Specifikation

## Allmänt

Typ av enhet	Mus
Trådlös mottagare	Trådlös USB-mottagare
Inriktning	Höger- och vänsterhänta
Bredd	6.7 cm
Djup	10.7 cm
Höjd	3.86 cm
Vikt	115 g
Färg	Svart

## Inmatningsenhet

Anslutningsteknik	Trådlös
Gränssnitt	2.4 GHz
Teknik för rörelsedetektering	Laser
Antal knappar	3
Rörelseupplösning	1600 dpi
Egenskaper	Softtouch-yta

## Expansion/Anslutning

Gränssnitt	1 x USB
------------	---------



## Diverse

**Standarder som följs**

CSA, UL, TUV GS, VCCI, BSMI, EN55022, SABS, SASO, EN55024, MIC, MOC, FCC, NTRA, ANATEL, UkrSEPRO, WPC, SRRC, CITC, NCC, iDA, BIS, ICASA, TRA, Subtel, CU-EAC, ACMA, EN 301 489-1-17, SIRIM, CONATEL, SDPPI, NRCS

## Batteri

**Teknik**

Litiumjon

**Kapacitet**

400 mAh

**Driftstid (upp till)**

3 månader

## Programvara / Systemkrav

**Operativsystem erfordras**

Microsoft Windows 7, Windows 10, Windows 8.x

## Kompatibilitetsinformation

**Designat för**

HP 240 G6, 240 G8, 245 G6, 245 G7, 246 G7, 250 G6, 250 G7, 250 G8, 255 G6, 255 G7, 255 G8, 340 G5, 340S G7, 348 G5, 470 G7 HP Chromebook 11 G6, 11 G7, 11 G8, 11A G6, 11A G8, 14 G5, 14 G6, 14A G5 HP Chromebook Enterprise 14 G6 HP Chromebook Enterprise x360 14E G1 HP Chromebook x360 11 G2, 11 G3, 14 G1 HP Elite c1030 Chromebook, c1030 Chromebook Enterprise HP Elite Dragonfly HP EliteBook 1040 G4, 1050 G1, 735 G5, 735 G6, 745 G5, 745 G6, 755 G5, 830 G5, 830 G6, 830 G7, 835 G7, 840 G5, 840 G6, 840 G7, 840r G4, 845 G7, 850 G5, 850 G6, 850 G7, 855 G7 HP EliteBook x360 1030 G3, 1030 G4, 1030 G7, 1040 G5, 1040 G6, 1040 G7, 830 G5, 830 G6, 830 G7 HP EliteDesk 705 G5, 805 G6 HP EliteOne 800 G6 HP Mobile Thin Client mt22, mt45, mt46 HP MX12 Retail Solution HP Pro c640 Chromebook, c645 Chromebook HP ProBook 430 G5, 430 G6, 430 G7, 430 G8, 440 G5, 440 G6, 440 G7, 440 G8, 445 G6, 445 G7, 445r G6, 450 G5, 450 G6, 450 G7, 450 G8, 455 G6, 455 G7, 455r G6, 470 G5, 630 G8, 635 Aero G7, 640 G4, 640 G5, 640 G8, 645 G4, 650 G4, 650 G5, 650 G8 HP ProBook x360 11 G2, 11 G3, 11 G4, 11 G5, 11 G6, 435 G7, 440 G1 HP ProDesk 405 G6 HP ProOne 400 G6, 440 G6 HP Spectre x360 15-ch006tx HP Stream Pro 11 G4 (Education Edition) HP Workstation Z1 G6 Entry, Z2 G5, Z2 Mini G5 HP ZBook 14u G4 Mobile Workstation, 14u G5 Mobile Workstation, 14u G6 Mobile Workstation, 15 G4 Mobile Workstation, 15 G5 Mobile Workstation, 15 G6 Mobile Workstation, 15u G5 Mobile Workstation, 15u G6 Mobile Workstation, 15v G5 Mobile Workstation, 17 G4 Mobile Workstation, 17 G5 Mobile Workstation, 17 G6 Mobile Workstation, Create G7, Power G7 Mobile Workstation, Studio G5 Mobile Workstation, Studio G7 Mobile Workstation, Studio x360 G5 Mobile Workstation HP ZBook Firefly 14 G7 Mobile Workstation, 15 G7 Mobile Workstation HP ZBook Fury 15 G7 Mobile Workstation, 17 G7 Mobile Workstation HP ZBook x2 G4 Detachable Workstation